



MacBook Pro 15" Retina Display Mid 2015

Lower Case Replacement

Replace the lower case on the MacBook Pro 15" Retina Display Mid 2015.

Written By: Andrew Optimus Goldberg



INTRODUCTION

Use this guide to help you replace a scratched, scuffed, bent or broken bottom panel on your MacBook Pro 15" Retina Display Mid 2015.



TOOLS:

- [P5 Pentalobe Screwdriver Retina MacBook Pro and Air](#) (1)



PARTS:

- [MacBook Pro 15" Retina \(Late 2013-Mid 2015\) Lower Case](#) (1)

Step 1 — Lower Case




- Remove the following pentalobe screws securing the lower case to the MacBook Pro:
 - Eight 3.1 mm
 - Two 2.3 mm



Step 2



- Lifting from the edge nearest the clutch cover, lift the lower case off the MacBook Pro.

Step 3



-  The lower case has two plastic pegs (red) that fit into plastic clips in the upper case (orange).
-  During reassembly, gently push down the center of the lower case to reattach the case to its two plastic clips.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-26 01:29:42 PM.